

ASSEMBLY GUIDE

945 PLAY GYM - PLAY TENT

P31 PRESSED LEAVES ROSE


02 GREY



IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

ASSEMBLY GUIDE MONTAGE SAMLEVEJLEDNING MONTERING


TOOLS NEEDED FOR ASSEMBLY





PARTS LIST

C12		x4	C13		x4	C14		x6	C15		x4
-----	---	----	-----	---	----	-----	--	----	-----	---	----


ASSEMBLED PLAY GYM






ASSEMBLED PLAY TENT




PLAY TENT COVER IN ORGANIC COTTON FABRIC **x1**





1.




2.




x4





3.






x2




4.



5.



6.



7.

